

GENERAL

Owner has selected the EarthCam [2 Camera Perimeter Detection](#) fixed system on their projects.

Contractor to purchase services direct from EarthCam.

EarthCam (System Vendor) will consult on and provide recommendations for optimal camera placement. Contractor will secure suitable vertical pole or column of at least 3" diameter and install the camera system. Contractor will contact System Vendor before installation and schedule system activation based on System Vendor recommendations.

The Contractor shall supply at the camera locations a dedicated, non-switched, 15Amp 120VAC circuit in the form of a securely covered outdoor rated outlet.

The Contractor shall provide all maintenance, including cleaning of the camera, throughout the life of the project and make appropriate arrangements for the cameras to remain in operation continuously and focused on the correct, unobstructed views to maintain security perimeter and/or detection zones. For maximum efficiency Contractor may be required to relocate cameras throughout the project in order to continue capturing the correct views as construction progresses.

At the conclusion of the project, Contractor will facilitate the removal and return shipping of the system using original shipping packaging and call tag provided by System Vendor. Instructions for return shipping will be provided by the System Vendor.

SYSTEM VENDOR EXECUTION OPTIONS

If optional solar power equipment is required, the Contractor will also need to install and orient the system as per vendor's instruction for proper operation. The Contractor shall supply all equipment required for safe and secure access to the camera location for installation and maintenance, including access, lift or ladders and scaffolding. A separate pole or mast for exterior camera mounting may be utilized, if required, also available from System Vendor.

The System Vendor may provide professional installation and removal services as an option to the Contractor.

Vendor of choice: EarthCam, Inc.

1-800-327-8422 www.earthcam.net/contact

Exec Team: +1-201-488-1111

execteam@earthcam.com



* 01 32 36 represents CSI Masterformat Construction Progress Video Monitoring and Documentation section number